

Black Mamba & Bushing Style Lifter Installation

1. These lifters have a special break-in lube between the axle and the roller wheel. "DO NOT WASH IN SOLVENT." Wipe the lifters off with a clean lint-free rag and install into engine.
2. These lifters need a break-in period with no load on motor for 25-30 minutes, varying the RPM from 1800-2200 RPM. After break-in re-lash lifters. The lash should not vary more than .001".
3. Do not use any oil restrictors.
4. Make sure the lifter to bore clearance on cast iron blocks is .0015"-.0017" and on aluminum blocks it is .0014"-.0016". The lifter bore roundness and taper should be a maximum of .0002". Following these clearances will give you good oil to the rocker arms while giving you good performance and durability.